

CMM

Remote Display for CA and CML Solar Charge Controller



- Measurement and display panel current, load current and battery voltage.
- · Clear, readable 3-digit LCD Display
- 3-position switch to select which value to be displayed
- 3 LEDs to show which value is displayed by LCD
- · Prepared for DIN rail and wall mounting

Phocos' CMM multi-meter is designed to measure and display panel current, load current and battery voltage of your PV system as true values. This provides you more detailed information of your PV system.

CMM can be used in combination with Phocos CA and CML series charge controllers.

Туре	СММ
Voltage range	0 to 35 V
Current range	0 to 25 A
Ambient temperature	−25 to +50 °C
Length of connecting wire	2 m
Dimensions of measuring component	84 x 44 x 32 mm
Dimensions of display component	72 x 68 x 29 mm
Weight	195 g (with connecting wire)
Type of protection	IP22